

This drawing is © Copyright of Etex Group. It must not be reproduced or altered in any part. This information is supplied in good faith but no liability can be accepted for any loss or damage resulting from use. Cedral and logos are trademarks of Etex NV or an affiliate thereof. Any use without authorisation is strictly prohibited and may violate trademark laws.

## Abutment with Continuous ventilation LR Breather Membrane Counter Battened

Breather membranes (Low Resistent) Must be counter battened as per requirements of BS 5250:2011, See BS 5534, S.R. 82:2017 for best code of practice

### Cedral Slates - With (LR) Breather Membrane

Rev. ...

#### Notes and specifications.

1. Stepped cavity tray
2. Metal cover flashing
3. Angled timber flashing support fixed to wall with downstand
4. Cedral CFV10 low profile over fascia vent fixed to upstand
5. 18mm min. wide continuous upstand fixed to timber grounds fixed to the wall at 600mm cntrs to provide 10mm gap with wall.
6. Metal apron flashing fixed to upstand
7. Suitable metal flashing clips at centres to suit exposure
8. Fibre Cement Slates
9. Slating battens
10. Counterbattens
11. Underlay carried up to upstand
12. Truss/Rafter
13. Extra wide top batten/double batten

Note: Not less than 40mm clear distance to be maintained between rafter/truss and chimney walls.

Use double-blank slates in alternate courses to side abutment. Fix with 3 no. copper nails and 2 no. copper crampions.

