


This drawing is © Copyright of Etex Group. It must not be reproduced or altered in any part. This information is supplied in good faith but no liability can be accepted for any loss or damage resulting from use. Cedral and logos are trademarks of Etex NV or an affiliate thereof. Any use without authorisation is strictly prohibited and may violate trademark laws.

Drawing Title - Abutment  
LR Breather Membrane Counter Battened

Breather membranes (Low Resistent) Must be counter battened as per requirements of BS 5250:2011, See BS 5534, S.R. 82:2017 for best code of practice

Cedral Slates - With (LR) Breather Membrane

Rev. ...



**Notes and specifications.**

1. Stepped cavity tray
2. Metal cover flashing
3. Metal soaker interleafed with Slates
4. Cedral Thrutone Slates
5. Slating Battens
6. Counter battens
7. Ventex Underlay carried up ends of battens
8. Truss/Rafter
9. External Wall

Note: Not less than 40mm clear distance to be maintained between rafter/truss and chimney walls.

Use Cedral double-blank slates in alternate courses to side abutment. Fix with 3 no. Tegral copper nails and 2 no. Tegral copper crampions.